

THE EUROPA UPGRADE FOR THE ROLAND JUPITER 6
INSTALLATION INSTRUCTIONS
VERSION 2.0



EUROPA INSTALLATION INSTRUCTIONS

COPYRIGHT

Copyright © 1994-2012 Synthcom Systems, Incorporated. All rights reserved. No part of this manual or CD-ROM (including cover design, illustrations, or interior design) may be reproduced or transmitted in any form by any means, including but not limited to electronic forms, photocopying, recording, or otherwise, without the prior written permission of Synthcom Systems, Incorporated. Visit <http://www.synthcom.com> for most current documentation, downloadable images, and support information.

LIMIT OF LIABILITY/DISCLAIMER OF WARRANTY

Synthcom Systems, Incorporated and its representatives have used their best efforts in preparing this CD-ROM and manual. Synthcom Systems, Inc. makes no representation or warranties with respect to the accuracy or completeness of the contents of the CD-ROM or files contained within it, and specifically disclaim any implied warranties or merchantability or fitness for any particular purpose, and shall in no event be liable for any loss of profit or any other commercial damage, including but not limited to special, incidental, consequential or other damages. Synthcom Systems, Incorporated reserves the right to update the files contained within this CD-ROM and is not required nor expected to ship updated CD-ROMs to existing owners.

TRADEMARKS

All brand names and product names used in this CD-ROM and manual are trademarks, registered trademarks, or trade names of their respective holders. Synthcom Systems, Incorporated is not associated with any product or vendor mentioned in this book, nor does it necessarily endorse any product or vendor.

INTRODUCTION

Welcome to the Europa upgrade for the Roland Jupiter 6! This document gives full installation instructions for upgrading the master controller board for the Jupiter 6 (JP-6). It is assumed that the reader has knowledge and experience with electronic hardware and associated tools. It is critically important that the instructions are followed *VERY* closely, as there are many small, but nonetheless important, details that are critical to the success of the upgrade. Proficiency with a soldering iron and a steady hand are required, so put down that cup of coffee! If you are not comfortable with the process documented here, do not attempt to install it yourself!

NOTE: Synthcom Systems, Inc. *cannot and will not be held liable* for third party installation that results in damage to the Europa chip itself, the JP-6's controller board, loss of patches, or any other part of the JP-6. This includes information in this document that may lead to damage of any part of the JP-6. Synthcom Systems, Inc. strives for accuracy in its installation instructions and reserves the right to modify them at any time for any reason. The installer assumes full responsibility for any damage done - regardless of fault. Proceed at your own risk! It assumed that the installer will read this document thoroughly before proceeding. Do not attempt if unsure!

CONCEPTUAL DESCRIPTION OF UPGRADE

The Europa upgrade is a replacement for the existing 8031 (or 8051) in the JP-6's controller board. It's a mostly pin compatible 40 pin DIP part (Temic T89C51RD2) that includes onboard flash where the Europa code resides. Additional electronic changes are documented below:

- The 8031/8051's !EA Is pulled high with a 1-10K ohm resistor allowing internal code execution
- Jumper removed to allow !EA to be strapped high
- XTAL1 And XTAL2 Are reversed due to NMOS (original 8031/8051 chip type) to CMOS conversion. NMOS Parts have pin 18 as the clock input and pin 19 as ground. The upgrade connects the clock input to pin 19 and ground to 18.
- Depending upon the version of the JP-6 controller board, the CPU may need to be removed and a socket put it in its place.

Flash programming voltage is obtained through the standard 5-volt supply of the chip so no additional jumpering is required.

EUROPA INSTALLATION INSTRUCTIONS

TOOLS YOU WILL NEED

This is a required list of tools needed to accomplish the Europa upgrade:

- Soldering iron
- Tiny wire cutters (snips)
- X-Acto knife or equivalent
- Desoldering tool (desoldering wick will **not** work well, and has mangled numerous PCBs)
- Flat or needle nosed pliers
- Small flat blade screwdriver
- Philips screwdriver
- Ohmmeter
- Pliers
- Antistatic bag or antistatic mat – at least 8 inches by 12 inches
- Safety goggles

The following tools are not necessary but will make the job much easier if they're available:

- Moto-Tool or die grinder with wire brush
- Small vice (rubber or plastic jaws only!)
- Desoldering station

The following parts are included in the upgrade. Please verify they are present before starting:

- 1 - Europa integrated circuit
- 1 - 4.7K Ohm resistor
- 1 - 40 Pin machine tooled socket
- 1 - 4 Inch wire. Must be small enough to wrap around soldered pins. Wire wrap gauge recommended.
- 1 - Replacement battery (only present if it was ordered - it is optional!)

NOTE: If a Kenton Jupiter 6 upgrade is currently installed, please contact support@synthcom.com for instructions on how to partially disconnect it to allow for peaceful coexistence with Europa.

GET STARTED!

Step 1) Clear a work area where the controller board can be easily modified. Ensure ahead of time that all aforementioned tools are present. *Be sure to back up your patches to tape or a computer's sound card!* Patches shouldn't be lost in this process, but it's good to have a copy just in case.

Step 2) Unplug all cables from the JP-6. Power, MIDI, CV inputs, headphones, pedals – anything that can be unplugged externally.

Step 3) Unscrew 3 screws on the left side of the JP-6 as shown in Figure 1 below (already removed - pointed to by the green arrows)



Figure 1 – JP-6 Side panel screw locations

There is an equivalent set of 3 screws on the opposite side of the JP-6. Remove them as well. Set them aside, and don't lose them!

Step 4) Unscrew the 3 front panel screws as shown in Figure 2 below:



Figure 2 – JP-6 front panel screw locations

EUROPA INSTALLATION INSTRUCTIONS

Step 5) Lift the control panel up – it is hinged at the rear of the JP-6. *Be careful not to lift the front panel so much that it stresses the wires pointed to by the green arrows in Figure 3!*




Figure 3 – Jack board – Watch that wire stress!

Step 6) Give the front panel support on each side with something long and solid, such as two screwdrivers or rulers. Use anything that will give the board adequate support without stressing/binding the wires on the jack board (shown in Figure 3).



Figure 4 – From left to right - 2 Voice board, controller (surrounded in green), and power supply

Step 7) Locate the controller board. It's the smaller board encircled in green in Figure 4. Don't be alarmed if the controller board is slightly different from what's pictured, as there are several different versions! Unplug all connectors going to the controller board. Make note of where the connectors go by labeling or taking a picture, as the connectors will need to be plugged back into their original locations when the controller board is reinstalled.

Step 8) There are 4 screws at the 4 corners of the controller board. Unscrew them and set the screws aside. **NOTE:** The screws are most likely secured with some sort of glue. Use a pair of pliers to break the seal. Firmly grab the screw with the pliers and turn until it pops. Then remove the screw with a screwdriver.

Step 9) WARNING: Touch the side of the JP-6 to discharge any static buildup that has potentially occurred. Remove the controller board and take it to the work area. Place the controller board on an antistatic bag or mat (Figure 5):





Figure 5 – Controller board with CPU (unsocketed) and EPROM labeled in green

Step 10) Put on work goggles or other eyewear to avoid injury! Determine if the controller board has a socketed CPU. If it doesn't, the CPU will need to be removed. If the board is socketed, remove the CPU from the socket and skip to step 14. Use a small flat blade screwdriver to pry up both ends of the CPU – **SLOWLY!**

EUROPA INSTALLATION INSTRUCTIONS

Step 11) With small wire cutters, clip every lead on the CPU. **NOTE:** This will destroy the chip when removing it, but the other alternative is desoldering. Desoldering will work, *but desoldering, even with the correct tools, increases the risk of lifting traces off the board.* A standard 8031/8051 is inexpensive compared to a controller board from Roland (if they are still available). Don't sacrifice a rare and expensive board for a plentiful inexpensive part!! There is no need to save the chip, as the Europa upgrade *is* a CPU that replaces the stock CPU. If available, remove the cut pins with a desoldering tool.



When cutting the pins on the CPU, do so with the cutting side of the cutters being as close as possible to where the pins are attached to the chip. The taller the pin, the easier the pins are to remove.

Be careful not to knock capacitors or other neighboring electronic components loose in the process.

After all pins are cut, the chip should lift out with no difficulty.

Figure 6 – Removing a soldered CPU

Step 12) After the CPU has been removed, place the controller board in a small vice – one with plastic or rubber jaws. **Do not use a metal jawed vice!** The vice should be applied at the edge of the board. **Be careful to avoid squeezing the components!** Use the soldering iron and a desoldering station (preferred) or solder sucker to remove each pin and the solder on **both** sides of the board.

Solder wick should not be used for this step, as it tends to lift traces on old circuit boards. We've had to repair several controller boards mangled by people who tried using solder wick, and it's not something we enjoy. If you don't know how to desolder properly, *please* let us install the upgrade for you.

Step 13) Use a small fiberglass or a die grinder with a brush attachment and clean off all solder pads with non-residue contact cleaner on both the top and bottom sides of the board. If you don't have one of these tools, use a pink pearl eraser. **Do not press so hard that traces are removed!** Because the solder pads have been oxidizing for the last 27+ years, cleaning them will help ensure that the solder will stick better.

To finish preparing the solder pads on the component side, tin them with fresh solder, **except the pad for pin 19.** You may wish to use a flux pen to help remove any remaining oxidation. Tinning may seem like a waste of time, but we have found that it greatly improves the chance of a successful socket installation. On many boards, the thru-holes are not plated through, so a good connection on the solder side does not guarantee a connection on the component side. If the pads aren't tinned, it can be difficult to get solder to wick through to them, even for experienced solderers.

When you're done tinning, clean off any flux that remains.

Step 14) Turn the board back over so it's sitting as shown in Figure 5. Locate the 74LS04 chip located next to the lower left corner of the CPU socket. It's pin 10 of the 74LS04 (located on the right side of the 74LS04 - 3rd pin from the bottom when the controller board is oriented like Figure 7). Notice the single trace that runs through a large ground trace (pictured in Figure 7).



Figure 7 – Clock line “trace to cut” illustration

Using an X-Acto or equivalent knife, cut the illustrated clock trace. Be sure to dig deep enough to actually cut it, but be careful not to slip and cut anything else!

Step 15) With a voltmeter, verify the resistance between pin 10 of the 74LS04 and pin 18 of the CPU socket (NOTE: It's the *third* pin from the bottom on the left column when oriented as in Figure 7 - *NOT the second!*). Resistance should read greater than 10 megohm or a completely open circuit.

Step 16) IMPORTANT: REFER TO Figure 10 FOR PIN REFERENCES! All traces surrounding pin 19 of the CPU must be cut so that pin 19 is no longer connected to ground. The traces are very small, and connect to the pad for pin 19 in one of two methods, each can be present on both the component and bottom side of the board. There are two connection styles to pin 19, the first being more common:




Figure 8 – Both possible connection styles to pin 19 and what to cut in each instance

Depending on the board revision, these traces may be found on the component side of the board as well as the bottom.

EUROPA INSTALLATION INSTRUCTIONS

Insert an X-Acto knife or equivalent under the socket on all 4 sides of pin 19, just outside the solder pad, and cut firmly until each trace is severed. If the circuit cannot be easily viewed from the top (component) side of the controller board, the socket must first be removed. Double check that both sides of the board have been cut if the board has traces on both sides to cut! Stray pieces of copper from the cut trace should be blown out of the way with compressed air. *Verify (with an ohmmeter) that there is no continuity between pins 19 and 20!*

If your board has a socketed CPU (a fairly rare occurrence), it can be quite difficult to cut the traces underneath the socket itself, *if you don't have the right tool*. We've found a dental pick to be perfect for this.

If the original socket has a closed-frame socket (has a solid top so the pc board isn't visible between the pin rows), it will need to be replaced with the provided machine tooled socket, as there is no way to cut around the pin. Even with an open-frame socket, you may have so much trouble reaching the traces that it's easier to remove the socket. In either case, remove the socket and jump back to step 13.

Step 17) Place the 40 pin machine tooled socket in the holes where the CPU was soldered. Use a machine tooled socket only (provided)! The socket and pins should go in easy – *don't force it!* If it doesn't, double check to ensure you haven't missed desoldering a hole or two. Once the socket is in place, solder down (on the bottom) all 4 corners of the socket. Be sure that the socket is as flush with the board as possible! If unsure, heat up the pin on the bottom of the board and push down from the top. Solder the remaining pins (illustrated in

Figure 9)




Figure 9 – Soldering down the 40 pin socket

An example of soldering the pins on the sockets is shown here. Remember good soldering technique – heat the work before applying the solder for a solid connection! Make sure each solder joint is shiny after it solidifies. Dull solder indicates a cold solder joint, which can cause intermittent operation or complete inoperability.

Feed enough solder to reach the other side of the pcb (about 1/8" or 3mm worth), but not so much that the pins are shorted. When finished, turn the board over and visually inspect the pins underneath the plastic part of the socket, to make sure there's solder between the pin and the pad beneath it, and also to make sure that solder didn't pool up and short between adjacent pins.

Step 18) Wire up the new clock lines. Solder a wire from pin 18 to pin 20 of IC12 (the CPU) on the bottom side of the PCB (as shown in Figure). Also solder a wire from pin 10 of the 74LS04 (IC20) to pin 19 on the CPU socket.




Figure 10 - Wire pin 10 on the 74LS04 to Pin 19, and Pin 18 of the CPU to pin 20 of the CPU

Step 19) Locate the jumper wire near the silk screened SW2. Note that this is not near any switch, but is as pictured in Figure 11. Remove the jumper by clipping it very close to the thru-holes. Turn the board over and clip the ends on the solder side, if necessary. You may find it easier to just desolder the jumper.



Figure 11 – Jumper wire before removal

Step 20) After the jumper has been removed, install a resistor (valued at 1K-10K Ohm) as shown in Figure 12. The installation location is indicated on the silkscreen as R29, and should be empty. Be sure to clip the ends off the resistor on the solder side of the board!




Figure 12 – Resistor (circled in green) installation shown (note that resistor value may vary!)

EUROPA INSTALLATION INSTRUCTIONS

Step 21) Now that all soldering has been completed, verify continuity between the CPU socket pins *on the component side of the board* and the following points. Do not press down so hard that you make a temporary connection between the pin and the pad beneath it.

CPU Pin #	Test Point	Board Location
1	CR1, pin 18	Connector at upper left, leftmost pin
2	CR1, pin 17	
3	CR1, pin 16	
4	CR1, pin 15	
5	CR1, pin 14	
6	IC5, pin 9	4053 to left of CPU
7	IC22, pin 19	40H245 near upper right corner
8	IC5, pin 10	4053 to left of CPU
9	IC9, pin 5	40H002 above CPU on left
10	R49, left leg	Resistor below CPU in middle
11	IC11, pin 5	LS40 just above CPU on left
12	NC	No Connection
13	TR2, pin 2	Transistor at middle left (maybe missing)
14	IC10, pin 5	40H002 above CPU on left
15	IC10, pin 9	
16	IC18, pin 4	40H138 above CPU on right
17	IC19, pin 5	40H138 just above CPU on right
18	CPU, pin 20	2 pins to the right on the CPU
19	IC20, pin 10	74LS04 just below CPU
20	IC19, pin 8	40H138 just above CPU on right
21	IC26, pin 23	EPROM to right of CPU
22	IC26, pin 22	
23	IC26, pin 19	
24	IC26, pin 21	
25	IC19, pin 1	40H138 just above CPU on right
26	IC19, pin 2	
27	IC19, pin 3	
28	NC	No Connection
29	IC26, pin 20	EPROM to right of CPU
30	TP1	Test Point 1 above CPU in middle
31	R29, left leg	Resistor that you installed in lower left
32	IC13, pin 11	ADC0803 just below CPU to left
33	IC13, pin 12	
34	IC13, pin 13	
35	IC13, pin 14	
36	IC13, pin 15	
37	IC13, pin 16	
38	IC13, pin 17	
39	IC13, pin 18	
40	IC19, pin 16	40H138 just above CPU on right

If you find a discontinuity, try feeding a little more solder to that pin. It may help to wipe off the soldering iron and press it into the top of the pin, until the solder melts and it seats firmly against the solder pad. Don't wiggle the iron or leave it on the pin too long, or the plastic will melt.

After you've tested for discontinuities, you should also verify that the resistance between adjacent pins (1 & 2, 2 & 3, etc.) is 100 ohms or more. A low resistance (10 ohms or less) indicates a short. If you find a short, remove the solder between the pins.

Step 22) Install the Europa chip as pictured in Figure 3. **NOTE: The notched end of the Europa chip faces away from the EPROM!** Every chip on the board mounted on the same axis as the CPU has the notched end facing the left side of the board (as pictured below), so if there is any doubt from this description or the picture, look at the orientation of the other chips. **DO NOT INSTALL THE CHIP BACKWARDS! THIS WILL RUIN IT!**



Figure 13 – Europa chip shown installed – Notched end to the LEFT!

Step 23) Look at the position of the Jig (sw1) switch – shown at the far left of Figure 3. Ensure that the switch is in the **NORM** position as silk-screened on the PCB. This is essential, as having it in the Jig position will cause the Roland code to execute when booted up. The Jig switch is used as a diagnostic tool only. See a Jupiter 6 service manual for more information regarding Jig based diagnostics.

Step 24) The board is now ready to be reinstalled! Place the controller board back in the JP-6. Install 2 of the board's 4 screws in opposing corners to secure it and keep it from sliding around and shorting out pins on the bottom. Reconnect all connectors removed in step 7. Make sure they're tight!

Step 25) Close the control panel. Ensure the JP-6 is switched off, and reconnect the power cable. **Ensure that write protect is turned off!** Write protect is a 3 position switch on the back panel of the JP-6. Ensure it's set to the center position.

Step 26) Power up the JP-6. The **A-F / 1-B** LEDs should strobe back and forth. This indicates that Europa is booting and it's waiting for the voice boards to respond and tune.

Step 27) The JP-6 should eventually show one or more "**E**" boot codes – typically **E-6** (see Appendix A for details on the specific Europa boot codes). "**E**" Boot codes will always show up on the first install of Europa. The regular Roland firmware does not check for NVRAM corruptions so it is entirely possible to have corrupted NVRAM without any indication! Europa default state settings are loaded in as well. Also, patches are converted from Roland format to Europa format and written to Europa's internal flash the first time Europa is powered up. This will appear as a flickering light for a period of a couple of seconds during first time bootup. Hit a key. The JP-6 will then boot up to operational Europa mode! Power down and back up again. Notice the light strobe sequence, followed by the **TUNE** LED, followed by normal board operation. Congratulations! Europa is working!

EUROPA INSTALLATION INSTRUCTIONS

Step 28) If the upgrade didn't go successfully, don't panic! Skip ahead to the **TROUBLESHOOTING** section.

Step 29) If everything worked as documented in step 27, it's time to make sure the other controller board cables were installed correctly. Try moving the LFO-1 Rate slider. If the LFO rate doesn't change, then the upper right pair of cables is reversed. Try selecting Split 2-4 mode and Poly 1 mode, and play two notes on the lower split and four on the upper split. Play six notes. If no notes are heard, the lower right pair of connectors is reversed. If four notes are heard, the lower left pair is reversed. If all six notes are heard, Europa is working correctly.

Shut off the JP-6, screw in the two remaining controller board screws, the 3 front panel screws, and the side panel screws (in that order). Upgrade complete! Please refer to the Europa owner's manual for Europa operation.

BATTERY REPLACEMENT


This section details battery replacement and installation. Batteries are optional – they are not part of the base Europa upgrade. A battery will not be provided if it wasn't specifically ordered!

Replacing the Jupiter 6's battery is a good idea. The factory-installed batteries had an original guaranteed life of 10 years, and are now over 20 years old!

If you haven't powered up Europa yet, **STOP**, unless you have a board with a dead or missing battery. **Installing the battery before powering Europa for the first time will result in the loss of the patch & preset data in NVRAM.** Go back to step 24, and don't proceed until Europa is fully operational. This is required so Europa will copy the patches and presets into Europa's flash memory.

Step 30) Remove the controller board again as documented in steps 7-9. *Put on protective eyewear or goggles to be protected from flying or exploding debris! This is a very important step, ESPECIALLY when dealing with lithium batteries!*

Step 31) Locate the original battery on the controller board:



Picture shows an example of a Roland factory battery. It is located in the lower left hand corner of the board as it is oriented in Figure 5.

The battery's type and appearance may vary from the photo in Figure 4 based on availability at the time of board manufacturing. The battery may also have been replaced during the Jupiter 6's life due to the prior battery dying.

Figure 14 - Factory battery

EUROPA INSTALLATION INSTRUCTIONS

TROUBLESHOOTING

No lights lit on power up other than LFO 1 rate and bender board LEDs - This typically indicates that the CPU isn't executing. Check for loose connectors. Reseat them. Look for bent pins on the Europa chip. Is a pin folded over? Power cable not plugged in all the way? Solder bridge on a few of the pins? Ensure pin 19 & 20 on the Europa chip are not shorted! With the board powered up, check for a 12 Mhz clock signal on pin 19 with an oscilloscope. Test for 5 volts on pin 31, and 0 volts on pin 18.

Board powers up immediately to operational code with no light strobe across A-F/1-B - The !EA pin is not strapped correctly. Double check the resistor installation (step 18). Test for 5 volts on pin 31. If this is not pulled up to 5 volts, code will execute out of the EPROM by default.

Board does light strobe across LEDs in upper left of front panel - the CR-1 & CL-1 cables on the upper left corner of the controller board have been reversed.

Board does light strobe show across A-F/1-B and eventually shows F-6 - One or both voice boards are not responding. Double check all connectors and be certain that the voice board cables (CM-2 & CM-4, on lower left of controller board) are not reversed.

Board shows error code on BANK A-F & NUMBER 1-B on bootup - Europa will show a status code on bootup with one bank light lit and one number light lit with only the **LFO-1** and **LFO-2** LEDs (possibly) blinking. Europa's onboard diagnostics well surpass that of the original Roland code. It will detect problems when the Roland code will not! See Appendix A for a description of all boot codes.

Playing notes in WHOLE and POLY 1 mode sounds no voices - the lower right pair of connectors, KC-1 & KC-2, is reversed.

Playing notes in WHOLE and POLY 1 mode has two missing voices (4 played notes, followed by two notes of silence, etc...) - the voice board cables (CM-2 & CM-4, on lower left of controller board) are reversed.

Knobs and sliders control the wrong sound settings - the connectors on the upper right, CR-3 & CL-3, are reversed.

Some other problem - remove the controller board, and tap an edge a few times on a table. It's possible that a chip leg or some copper debris is shorting something. Remove the CPU and use a magnifying glass to inspect for knife cuts on the pcb. We've had several cases where someone unknowingly cut the wrong circuit trace with a slip of the knife while performing steps 14 or 16! Finally, make sure you didn't miss something important. Carefully retrace the steps in this installation guide, especially step 21. Over 95% of failed installations have been due to improper socket installation.

When all else fails - don't panic! Europa is a very simple upgrade with little to go wrong. Hundreds of Jupiters have been upgraded with Europa, and we've yet to encounter one that is incompatible with the upgrade. The Synthcom support staff is very experienced at dealing with installation problems. Email a detailed description of your problem to support@synthcom.com, or call us at (832) EUROPA6 (832-387-6726) between 12PM-6PM Pacific time for further troubleshooting assistance.

APPENDIX A – BOOT CODES

If the board finishes its LED strobe boot sequence with all LEDs off except for one bank light lit and one number light lit or flashing, and possibly the **LFO-1** and **LFO-2** LEDs flashing, it indicates that the Europa firmware has encountered an unexpected condition, and is displaying a code to indicate what it thinks is going on. Some codes indicate hardware errors, some indicate programming is in progress, and some indicate data errors. The meaning of each code is described in this appendix.

Occasionally, an accidentally cut trace or shorted pin will cause an incorrect boot code, as there are limits to what the firmware can detect when the hardware is malfunctioning.

GROUP A BOOT CODES

The **A** group of boot codes indicate unrecoverable component diagnostic failures in either the Europa chip itself or the scratch RAM chip on the controller board. They are not recoverable, and Europa will not run, even when a :

- A-1** Internal CPU RAM failure. This is a failure of the Europa chip itself. If the Europa is still under warranty, contact Synthcom Systems, Inc. for arrangement of replacement.
- A-2** Scratch RAM failure. This failure occurs when Europa cannot get reliable data communication with the scratch RAM chip on the Jupiter 6's controller board. Either the scratch RAM chip itself is bad or the interconnecting circuitry is making communication with it unreliable. *This is not a failure with the Europa chip!* If this occurs directly after a Europa installation, look for solder bridges or unintentionally cut traces.
- A-3** Internal "external" CPU RAM failure. The Europa chip contains an additional 1K of onboard static RAM and this indicates its failure. This is a failure with the Europa chip itself. As with boot code **A-1**, contact Synthcom Systems, Inc. for arrangement of replacement if still under warranty.

GROUP B BOOT CODES

The **B** group of boot codes indicates that Europa is executing firmware transfer mode rather than Europa itself. It is indicated by the **B BANK** LED being lit solid and one **1-B NUMBER** LED lit solidly with all other **NUMBER** LEDs blinking. All **B** group codes are recoverable:

- B-1** Europa image is bad, not present, or **TAPE + WRITE** (force Firmware Transfer Mode) was held on board powerup. The Jupiter 6 is waiting for a Europa image to be programmed in. This code can come up if a prior Europa firmware update failed or the Europa image is bad. Not to worry! This just means the Europa Firmware Update Utility needs to send the board a good image! The Europa chip as it comes from Synthcom Systems will contain a fully tested image and this will not happen.
- B-2** Europa image area prepared and awaiting programming.
- B-3** Europa programming in process.
- B-4** Europa programming complete. Check code/image is good!
- B-5** Europa programming complete. Check code/image is bad!

EUROPA INSTALLATION INSTRUCTIONS

GROUP E BOOT CODES

The **E** group of boot codes indicates diagnostic failures that Europa has detected and corrected. For example, it's possible for **E-6** to be shown, (requiring pressing a button/key), followed by **E-2** (also requiring pressing a button/key). Pressing a button or key will cause the board to continue the bootup process. More than one **E** code can be shown simultaneously as well as sequentially:

- E-1** Bad patch data found in flash and corrected. This is indicative of the Europa chip beginning to fail or a bug in Europa that has trashed the patch storage in flash. Please contact Synthcom Systems for replacement (if under warranty). Corrections can occur even if write protect is thrown, because the flash writability isn't controlled by the memory protect switch.
- E-2** Indicates operator has pressed the portamento button and powered the Jupiter 6 on – causing the contents of the NVRAM to be copied in to flash.
- E-3** Bad preset data found in flash and corrected. This is identical to **E-1** in terms of root cause.
- E-4** Bad Europa board settings found and defaults loaded. Europa uses part of the NVRAM for storing current board state and settings. This code is shown when the area contains bad/bogus settings. This failure can also be shown when the board is first powered up after Europa is installed, the controller board's battery is going bad, or if a boot to the Roland code was performed. This is what is shown after a first time installation.
- E-5** Bad Europa board settings checksum – defaults loaded. Similar to code **E-4** listed above, the checksum of the board settings area is bogus. Checksums are not reliable enough to detect all corruptions, so both checking in-block data and entire block data is needed.
- E-6** Roland factory patches reloaded. This occurs when Europa has been ordered to reload Roland factory patches/presets into its NVRAM and flash via holding **BENDER** and powering the board on.
- E-7** Patches and presets copied from internal flash to NVRAM. This converts presets from Europa format back to Roland format so the Roland code can read the patches and presets. Note that many Europa specific settings are lost if the data is copied to NVRAM, and then back to flash.

GROUP F BOOT CODES

The **F** group of boot codes indicate diagnostic failures that Europa has detected, but cannot correct, due to the memory protect switch being on. One or more of these codes will be shown, but the board will not boot further, as they are hard failures that need to be corrected before board execution can occur:

- F-4 TO F-5** Identical to **E-4** and **E-5** as listed in the prior **E** group section, but the conditions are not correctable due to the memory protect switch being on. To correct, power off the Jupiter 6, disable the memory protect, and power the Jupiter 6 on.
- F-6** Indicates that one or both voice boards are not responding. This fault can also show up if the voice boards' connections to the controller board were installed backwards or aren't making a solid connection to the controller board.
- F-7** Identical to **E-7** above, but indicates that the copy to NVRAM isn't possible because the memory protect switch is on.

EUROPA INSTALLATION INSTRUCTIONS

For convenience, Europa's Powerup diagnostic flowchart is as follows:

